


## PAX S80 Restaurant/Retail Quick Reference Guide

Password is always today's date Example 6/22/2017 is 06222017 12/5/2018 is 12052018 etc.

Josh Mandell (973-253-4077) Josh@envoybusinesssystems.com





## MANUALLY KEYED IN SALE (CONT.) **DEBIT SALE (CONT.)** Display Action Display Action **E 7.** Enter the CVV2 code. E **5.** Enter the 4 digit PIN on F2 F2 ENTER CVV2: then press **ENTER**. the attached PIN Pad. Please Enter PIN F3 F3 on the PIN Pad If you do not have then press ENTER. F4 access to, or cannot read the CVV2 code. **(ii**) 6. Terminal will begin CVV2 code is located on the back press **ENTER** to skip of the customer card, or the front F2 Printing... printing receipt this step. of American Express cards. F3 while processing the transaction. **8.** If you skipped step 7, EXPLAIN REASON: 1. Want to bypass F2 select the reason why. 7. Press ENTER for a F3 2. Cannot read F2 customer copy, or press F4 Tear Slin---> 3. Does not exist F3 Press Any Key... CANCEL to return to the Fi 9. Enter the zip code home screen. ENTER ZIP CODE: F2 of the card's billing **EBT SALE** F3 address, then press F4 ENTER Display Action 10. Terminal will begin (FI 1. Press **F3** twice to toggle F2 printing receipt Printing... F2 F3 PRESS ENTER the payment type to EBT, while processing the F3 EBT then press ENTER. transaction. SALE F4 11. Press ENTER for a FI SELECT EBT TYPE: **E** 2. Select the type of sale. F2 customer copy, or Tear Slip----> 1. FoodStamp F2 F3 Press Any Key... press **CANCEL** to F3 2. CashBenefit return to the home 3. Voucher F4 screen. FI EBT SALE 3. Enter the sale amount. **DEBIT SALE** F2 AMOUNT 0.00 then press **ENTER**. F3 F4 Display Action (FI) 1. Press **F3** to toggle ø **4.** Swipe the card or key in F2 F2 SWIPE CARD/INPUT the card number, then INPUT AMOUNT the payment type F3 ACCOUNT F3 DEBIT to DEBIT, enter sale press ENTER. SALE amount, then press ENTER **5.** Enter server number if F2 ENTER SERVER ID: prompted, then press Enter TIP1 2. Enter tip amount, then F3 ENTER. F2 AMOUNT 0.00 press ENTER. F4 F3 RESTAURANT ONLY RESTAURANT ONLY. F4 E 6. Enter the 4 digit PIN on F2 **E** 3. Swipe the debit card. the attached PIN Pad. Digaso Entor DIN F2 on the PIN Pad F3 SWIPE CARD then press ENTER. F3 F4 F4 7. Terminal will begin printing (EI) 4. Enter server number if F2 Printing... receipt while processing F3 F2 ENTER SERVER ID: prompted, then press the transaction. F3 ENTER. RESTAURANT ONLY.

## **EBT SALE** (CONT.) **VOID** Display Action Display Action FI 8. Press ENTER for a (E) 1. Press the **FUNC** key F2 F2 INPUT AMOUNT customer copy, or located on the top right Tear Slip----> F3 Press Any Key... F3 CREDIT corner of the keypad. press **CANCEL** to SALE F4 return to the home screen 2. Press 7 to select the Void FUNCTION MENU: (E) F2 1. Report function. **FORCED SALE** 2. Batch F3 3. Review F4 4. Find Display Action 3. Enter server number if 1. Press F4 three times F2 **ENTER SERVER ID:** prompted, then press INPUT AMOUNT F2 to toggle the sale type F3 ENTER. F3 CREDIT to FORCED, enter sale F4 F4 RESTAURANT ONLY FORCED amount, then press ENTER. (EI) **4.** Enter the transaction F2 ENTER TRANS #: number of the sale you E Enter TIP1 2. Enter tip amount, then F3 would like to void, then AMOUNT 0.00 F2 press ENTER. F4 press ENTER. F3 RESTAURANT ONLY. F4 F1 5. Screen will display the #0000 SALE **(i)** AMOUNT 0.00 F2 transaction details. If 3. Swipe the card or key \*\*\*\*\*\*\*\*\*1734 F3 F2 in the card number, display is correct, press SWIPE CARD/INPUT F4 ACCOUNT F3 then press **ENTER**. **ENTER**. If display is not F4 correct, press **CANCEL** to return to the home screen. (FI) 4. Enter the 6 digit F2 ENTER AUTH. # authorization number. E1 6. Confirm voiding the Void #0000? F3 then press **ENTER**. F2 ENTR=YES, CANC=NO transaction by pressing F4 F3 ENTER, or press CANCEL F4 to return to the home Fi 5. Enter server number if screen. F2 ENTER SERVER ID: prompted, then press F3 ENTER. 7. Terminal will begin printing F4 RESTAURANT ONLY. F2 Printing... receipt while processing F3 the transaction. FI 6. Terminal will begin F4 F2 Printing... printing receipt F3 while processing the F1 8. Press ENTER for a F4 F2 transaction. customer copy, or press Tear Slip----> Press Any Key... F3 **CANCEL** to return to the 7. Press ENTER for a (FI F4 home screen. F2 customer copy, or Tear Slip----> Press Any Key... F3 press **CANCEL** to **REFUND** return to the home screen. Display Action E 1. Press the **FUNC** key F2 INPUT AMOUNT located on the top right F3 CREDIT corner of the keypad. SALE F4 FUNCTION MENU: (E) 2. Press 8 to select the F2 1. Report Return function. 2. Batch F3 3. Review F4 4. Find

