

# Quick Reference Guide



VP100

Dual Pricing



#### **CARD SALE AND CASH SALE**

- 1. Enter Transaction Amount and press OK.
- Swipe/Insert/Tap card on Present Card screen or start typing card number for Manual Entry.
- 3. Sign and Tip if prompted.
- 4. Select receipt delivery method.

#### EBT FOOD/CASH SALE

- **1.** Tap the **Menu** icon (≡)
- 2. Tap Option 1 (Payment).
- 3. Tap either EBT Food or EBT Cash.
- 4. Tap Sale.
- 5. Enter Transaction Amount and press OK.
- Swipe/Insert/Tap card on Present Card screen or start typing card number for Manual Entry.
- **7.** Select receipt delivery method.

#### **CREDIT VOID**

- 1. Tap the Menu icon (≡)
- 2. Tap Option 1 (Payment), tap Card then tap Void.
- Select Tran Number or Card Number. If Tran Number, enter transaction number. If Card Number, enter last 4 digits of card.
- **4.** Transaction will appear on screen. Press **OK** to void transaction.
- 5. Select receipt delivery method.

#### **CREDIT REFUND**

- 1. Tap the Menu icon (≡)
- 2. Tap Option 1 (Payment), tap Card then tap Refund.
- 3. Enter Refund Amount and press OK.
- Swipe/Insert/Tap card on Present Card screen or start typing card number for Manual Entry.
- 5. Select receipt delivery method.



### **Favorites Menu**

**REPRINT RECEIPT** | Print receipt for last transaction.

**SETTLEMENT** | Option to settle the current batch.

**TIP ADJUST** | Adjust the tip amount on transactions performed within current batch.

**REPORTS** | See summary reports for current open batch, the last settled batch, and the detailed reports of the last 5 batches settled.

**CHANGE PASSWORD** | Set one general password **OR** create custom passwords for settlements, voids\refunds & removing custom fee.

**DOWNLOAD PACKAGE** | Applies parameter changes or updates version on device.

**COMM CONFIG** | Configure your internet connection settings.

**REBOOT** | Power cycles device.

**REMOTE DIAGNOSTICS** | Allows ISO to remotely troubleshoot the device.




# **Connect to WiFi**

- From the Home Screen, tap (★) 7 Comm Config.
- 2. Tap Comm Config, tap WiFi, tap the SSID, then tap Configure.
- Enter WiFi Password. Please note WiFi Password is case sensitive.
- **4.** Tap **OK** to confirm, press the **Cancel** button, then tap **Connect.**

**To fast swap connection, tap Connection Icon** (see Terminal Guide for location).

## **Terminal Guide**



- 1. Connection Icon
- 2. Card
- 3. Cash
- 4. Main Menu
- **5.** Favorite Icon
- 6. Contact Support
- 7. Hold to power down terminal
- 8. Press to feed paper
- 9. Enter / Confirm Selection
- 10. Main Menu on Keypad





