

Set the Date/Time

Step	Action	Display
1.	Press the [MENU] button	
2.	Enter the current password and press [ENTER]	ENTER PASSWORD:
3.	From the main menu, press [5] to access System Settings	MAIN MENU: 2. Merchant Settings 3. Operation Settings 4. Hosts Settings 5. System Settings
4.	From System Options screen, press [1] to access Date/Time Setup	SYSTEM OPTIONS: 1. Date/Time Setup 2. Batch Number 3. Working Mode 4. Pre-Dial Call
5.	Verify that the current Date and/or Time are correct. If incorrect, input the correct date using MM/DD/YY format. Press [ENTER]	07/31/06 MM/DD/YY 10:02:49 HH:MM:SS
7.	Input the correct hour and minute using Military (24-hour) Format. Press [ENTER] when finished	07/31/06 MM/DD/YY 10:02:49 HH:MM:SS