## S80 on TSYS

Term not authenticated- have them go into host settings, host register then activate. This happens on TSYS with debit